




©2016 Aqua-Leisure® Industries, Inc. Contact: call 1-866-807-3998, send e-mail to customercare@aqualeisure.com, or mail to Aqua-Leisure Industries, P.O. Box 239, Avon, MA 02322-1098. Styles and colors may vary. Distributed by Aqua-Leisure Industries, Inc. **Visit us at Aqualeisure.com**

Yarra River Chair



WARRANTY

Return product to retailer with proof of purchase. Product is covered by a 90-day warranty from the original purchase date, under normal use, and against defective workmanship and materials.

DUOLOCK is a trademark of Aqua-Leisure Industries, Inc.

⚠️ PRODUCT WARNINGS and GUIDELINES: READ THIS INFORMATION CAREFULLY

To reduce the risk of injury or death, please follow these warnings and guidelines:

- This is not a life-saving device.
- Do not exceed the manufacturer's recommended number of person(s) as shown on package.
- Do not use this product if damaged.
- Product is not intended for use by children under 15 years of age. Adult supervision required.
- Do not over-inflate or use high-pressure air to inflate.
- Product is to be used **ONLY ON WATER**. **DO NOT USE OR DRAG ACROSS ANY LAND SURFACE** including driveways, yards, gravel, beaches, or shore line areas. Do not tow this product.
- Diving or jumping into water from this product is **NOT RECOMMENDED**.

PRODUCT INSTRUCTIONS and FOOTREST HINGE TROUBLESHOOTING

To inflate, open STANDARD or FAST inflation valve, inflate, and insert LOCK plug firmly into valve (A). Footrest Troubleshooting: Should footrest hinge(s) separate the from inner panel wall, deflate product by opening FAST valve to release air (A). To reattach hinge(s) on Footrest; align and insert each Footrest hinge cap into socket on chair inner wall and rotate counterclockwise to lock (see B). Inflate product.

NOTE: Chair can be used with other Lock 'n Dock™ products by attaching carabiners together (see C). Vinyl plastic repair kit enclosed.

