

GROW WITH ME 2-IN-1

Baby Boat with Removable Flotation Trainer

PRODUCT WARNINGS and GUIDELINES: READ INFORMATION CAREFULLY

To reduce the risk of injury or death, please follow these warnings and guidelines:

- This product is not a life-saving device. NEVER leave child unattended while in use.
- Use only under competent adult supervision. Adult assembly is required. Keep instructions for future reference.
- See front of package for recommended age of child.
- DO NOT use with a baby who cannot sit confidently.
- NEVER use Baby Boat without the Flotation Trainer.
- The possibility DOES exist that a baby could tip the unit over. To reduce risk of this happening, ensure water level is deep enough where baby cannot touch bottom.
- Exercise extra caution when baby is teething, she/he could puncture the baby boat.
- DO NOT give baby playing accessories that could potentially damage this product.
- DO NOT use this product if damaged. Check seams regularly for tears.

INSTRUCTIONS FOR ASSEMBLY

- Inflate Baby Boat and Sunshade until each is firm. DO NOT overinflate or use high-pressure air to inflate. For best results, finish inflating Boat and Sunshade by mouth and ensure each cap is placed firmly into the valves of both products (see A).
- Attach Sunshade. Place Boat in front of you (logo facing forward) and align Shade over Boat with Shade's straight edge facing forward (curved edge backward). Squeeze each knob on the Boat's sides and insert it into each opening on sides of the Shade (see B).
- The Flotation Trainer is designed with a dual-chamber inner tube to provide an extra level of safety in the unlikely event a chamber loses air/deflates. Inflate rings in order: inflate INNER RING valve first ① and OUTER RING valve second ② (see C). Do not overinflate or use high-pressure air to inflate. Again, for best results, finish inflating the Trainer by mouth and ensure caps are placed firmly into the valves (see A).

PLACING FLOTATION TRAINER ON BABY







- Release the buckles on the bottom strap and position the ring over your child. Ensure your child's arms and head are through the openings of the Trainer before sliding ring downwards to the child's waist, valves should be in back of child.
- Reconnect the front and back buckle and adjust the length of the strap (see D). The strap should be loose enough to be comfortable, yet tight enough to prevent the ring from "riding" up on your child.

INSTRUCTIONS FOR USE and SAFETY

- When baby is first being introduced to the water, place your child wearing the Flotation Trainer into the Baby Boat. The ring will fit into place in the boat and add another layer of security (see E). With child in the boat, adjust shade to block the sun. PLEASE NOTE: Use sunscreen on child and limit your child's exposure to the sun.
- Once your child gains water confidence, use of the Boat is unnecessary: you may place your child in the water with only the Flotation Trainer.

PRODUCT CARE

- Flotation Trainer - Hand wash in cold water with mild detergent. Do not bleach, iron, or use hot water. Do not place in washing machine. Baby Boat - Rinse with clean water.
- Do not allow products to be exposed to direct sunlight for extended periods of time, and store in a cool, dry place.
- Vinyl Plastic Repair Kit is enclosed.



WARRANTY

Return product to retailer with proof of purchase. Product is covered by a 30-day warranty from the original purchase date, under normal use, and against defective workmanship and materials.