



Learn more at  
[Originalswimschool.com](http://Originalswimschool.com)



## Fabric Arm Floats

### WARRANTY

Return product to retailer with proof of purchase. Product is covered by a 30-day warranty from the original purchase date, under normal use, and against defective workmanship and materials.



©2016 Aqua-Leisure® Industries, Inc. Contact: call 1-866-807-3998, send e-mail to [customercare@aqualeisure.com](mailto:customercare@aqualeisure.com), or mail to Aqua-Leisure Industries, P.O. Box 239, Avon, MA 02322-1098. Styles and colors may vary. Distributed by Aqua-Leisure Industries, Inc.

### **▲ PRODUCT WARNINGS and GUIDELINES: READ THIS INFORMATION CAREFULLY**

To reduce the risk of injury or death, please follow these warnings and guidelines:

- These products are not life-saving devices. Do not leave child unattended while in use.
- Use only under competent adult supervision.
- See package for recommended weight of child.
- Products are only to be used on child in water in which the child is within its depth.
- DO NOT use these products if damaged. Check seams regularly for tears.
- DO NOT allow child to dive into water head first.

### INSTRUCTIONS FOR USE and SAFETY

To reduce the risk of injury or death, please follow these instructions:

- Inflate arm floats before use (see A). Inflate air chambers in order: inflate “strap side” valve first, and “patch side” second (see B). For best results, finish inflating floats by mouth and ensure caps are placed firmly into the valves (see C).
- Once inflated, insert child’s arms through openings of arm floats and move to upper arms, secure onto arm by attaching hook-and-loop strap to fabric patch (see B).
- Enter water with your child. Always stay in pool within arm’s reach of your child.
- Use arm floats as your child builds his/her swimming skills.

