



©2016 Aqua-Leisure® Industries, Inc. Contact: call 1-866-807-3998, send e-mail to customercare@aqualeisure.com, or mail to Aqua-Leisure Industries, P.O. Box 239, Avon, MA 02322-1098. Styles and colors may vary. Distributed by Aqua-Leisure Industries, Inc.

Water Sport Gear



Visit us at
Aqualeisure.com

WARRANTY

Return product to retailer with proof of purchase. Product is covered by a 90-day warranty from the original purchase date, under normal use, and against defective workmanship and materials.

DUOLOCK is a trademark of Aqua-Leisure Industries, Inc.

▲ PRODUCT WARNINGS and GUIDELINES: READ THIS INFORMATION CAREFULLY


To reduce the risk of injury or death, please follow these warnings and guidelines:

- This is not a lifesaving device.
- Do not use this product if damaged. Check seams regularly for tears.
- Product is not intended for use by children under 15 years of age. Adult supervision required.
- Product is to be used **ONLY ON WATER**. **DO NOT USE OR DRAG ACROSS ANY LAND SURFACE** including driveways, yards, gravel, beaches, or shore line areas. Do not tow this product.
- Diving or jumping into water from this product is **NOT RECOMMENDED**.

INSTRUCTIONS for USE

- To inflate, open STANDARD or FAST inflation valve, inflate, and insert LOCK plug firmly into valve (A).
- Do not over-inflate or use high-pressure air to inflate. For best results, finish inflating the product by mouth and ensure the cap is placed firmly into the valve.
- Vinyl plastic repair kit enclosed.

SPECIAL NOTE: Water Sport Gear can used with other Lock 'n Dock products by attaching carabiners together (see B).



B Carabiner

