

FLOTATION TRAINER




PRODUCT WARNINGS and GUIDELINES: READ INFORMATION

To reduce the risk of injury or death, please follow these warnings and guidelines:

- This product is not a life-saving device. NEVER leave child unattended while in use.
- Use only under competent adult supervision. Keep instructions for reference.
- See front of package for recommended age of child.
- DO NOT use with a baby who cannot sit confidently.
- The possibility DOES exist that a baby could tip the unit over. To reduce risk of this happening, ensure water level is deep enough where baby cannot touch bottom.
- Exercise extra caution when baby is teething, she/he could puncture the trainer.
- DO NOT give baby playing accessories that could potentially damage this product.
- DO NOT use this product if damaged. Check seams regularly for tears.




INSTRUCTIONS FOR ASSEMBLY

- The Flotation Trainer is designed with a dual-chamber inner tube to provide an extra level of safety in the unlikely event a chamber loses air/deflates.
- Inflate rings in order: inflate INNER RING valve first ① and OUTER RING valve second ② (see A). Do not overinflate or use high-pressure air to inflate. For best results, finish inflating Trainer by mouth and ensure caps are placed firmly into the valves (see B).



PLACING FLOTATION TRAINER ON CHILD and SAFETY

- When placing the trainer on your child, release the buckles on the bottom strap and position the ring over him/her. Ensure your child's arms and head are through the openings of the Trainer before sliding the ring downwards to your child's waist, valves should be in back of your child (see C).
- Reconnect the front and back buckle and adjust the length of the strap (see D). The strap should be loose enough to be comfortable, yet tight enough to prevent the ring from "riding" up on your child.
- Please Note: Use sunscreen on your child when using this product and limit your child's exposure to the sun.



PRODUCT CARE

- Flotation Trainer - Hand wash in cold water with mild detergent. Do not bleach, iron, or use hot water. Do not place in washing machine.
- Vinyl Plastic Repair Kit - To repair a puncture, deflate item, clean, and dry area for 10 minutes. Cut vinyl to the correct size to cover the puncture, place patch over area and press firmly. Wait 20 minutes before re-inflating.

WARRANTY

Return product to retailer with proof of purchase. Product is covered by a 30-day warranty from the original purchase date, under normal use, and against defective workmanship and materials.